PRODUCT DATASHEET

WF-058/060

Wall Feed Thru for FLEXWELL® Elliptical Waveguide E58 and E60

The kit consists of wall gland, a single rubber boot and tension clamp with two bolts.

FEATURES / BENEFITS

Elliptical Waveguide installation

- The wall gland provides a single entry in conjunction with a feed through plate
- It consists of a single rubber boot, wall gland and stainless steel clamp



External Document Links

Installation Instruction

Notes

Technical features

STRUCTURE		
Product Line		Elliptical Waveguide Accessories
Product Type		Wall/Roof Feed-Through System
Feed-Through Component		Single Entry Kit
Transmission Line Type		E58, EP58, E60, EP60
MECHANICAL SPECIFICATIONS		
Feed-Through Holes		1
Feed-Through Hole Diameter	mm (in)	70 (2.76)
PACKAGING INFORMATION		
Package Quantity		1

All values nominal unless tolerances provided; information contained in the present datasheet is subject to confirmation at time of ordering