

# Connector for FLEXWELL® elliptical waveguide E78, CPR137G Flange

Standard connector for FLEXWELL® elliptical waveguide E78 with CPR137G flange, gasket sealed frequency range: 7.125 - 7.75 GHz

FEATURES / BENEFITS

### **Superior Design**

- Fewer tuning screws
- Better performance

# **Quick & Easy Installation**

- Flaring tools not required
- Assemble using standard hand tools performance

C78-137E Standard

### **Assorted Connector Types**

- Standard (non-tunable), tunable and pre-tuned versions are available
- Two basic interface series flange can mate with either a choke or a cover flange

# **Technical features**

#### **STRUCTURE**

Transmission Line Type		Elliptical Waveguide
Cable Type		E78
Model Series		E78 Series
Connector Frequency Range	GHz	7.125 - 7.75
Connector Type		Non-tunable
Sealing Method		Gasket
Gas Inlet		NPT 1/8
Connector Interface		CPR137G

# **MECHANICAL SPECIFICATIONS**

Length	mm (in)	96 (3.8)
Outer Diameter	mm (in)	56 (2.2)
Weight	kg (lb)	0.7 (1.54)

REV DATE: 15 Sep 2021

# External Document Links Installation Instruction

#### Notes

C137-078FG

Use only on standard waveguide (premium performancewill not be achieved using premium waveguide).

www.rfstechnologies.com

REV: C