



**WF-065**

Wall Feed Thru for FLEXWELL® Elliptical Waveguide E65

The kit consists of wall gland, a single rubber boot and tension clamp with two bolts.

**FEATURES / BENEFITS**

**Elliptical Waveguide installation**

- The wall gland provides a single entry in conjunction with a feed through plate
- It consists of a single rubber boot, wall gland and stainless steel clamp



[External Document Links](#)  
[Installation Instruction](#)

[Notes](#)

**Technical features**

**STRUCTURE**

<b>Product Line</b>		Elliptical Waveguide Accessories
<b>Product Type</b>		Wall/Roof Feed-Through System
<b>Feed-Through Component</b>		Single Entry Kit
<b>Transmission Line Type</b>		E65, EP65

**MECHANICAL SPECIFICATIONS**

<b>Feed-Through Holes</b>		1
<b>Feed-Through Hole Diameter</b>	mm (in)	70 (2.76)

**PACKAGING INFORMATION**

<b>Package Quantity</b>		1
-------------------------	--	---